

NZ CB Radio Channels					
Ch	NZ UHF (MHz)	NZ HF (MHz)	Ch	NZ UHF (MHz)	NZ HF (MHz)
1	476.425	26.330	21	476.925	26.580
2	476.450	26.340	22	476.950	26.590
3	476.475	26.350	23	476.975	26.620
4	476.500	26.370	24	477.000	26.600
5	476.525	26.380	25	477.025	26.610
6	476.550	26.390	26	477.050	26.630
7	476.575	26.400	27	477.075	26.640
8	476.600	26.420	28	477.100	26.650
9	476.625	26.430	29	477.125	26.660
10	476.650	26.440	30	477.150	26.670
11	476.675	26.450	31	477.175	26.680
12	476.700	26.470	32	477.200	26.690
13	476.725	26.480	33	477.225	26.700
14	476.750	26.490	34	477.250	26.710
15	476.775	26.500	35	477.275	26.720
16	476.800	26.520	36	477.300	26.730
17	476.825	26.530	37	477.325	26.740
18	476.850	26.540	38	477.350	26.750
19	476.875	26.550	39	477.375	26.760
20	476.900	26.570	40	477.400	26.770

Emergency Channels & Calling Channels	
NZ HF	Ch.15
Notes:	NZ Channels 1-24 are for AM use only. NZ Channels 25-40 are for SSB use only.